

# NYSEAL® 2.0 FINISH STUDY TEST

NYSEAL® 2.0 MACDERMID		Delamination 5x Install (Pass/Fail)	Pressure Test 10 PSI/1min 5x Install
<b>Zn E-Plate</b>	MacDermid Zinklاد 250 Basecoat	✓	✓
	MacDermid Zinklاد 250 Basecoat + Topcoat (TNT-15)		
<b>Silicate</b>	MacDermid Zinklاد 250 Basecoat (JS500)	✓	✓
<b>ZnNi E-Plate</b>	MacDermid Zinklاد 1000 Clear (Basecoat only)	✓	✓
	MacDermid Zinklاد 1000 Clear (Basecoat + Topcoat) (TNT-12)		
	MacDermid Zinklاد 1000B EXP Basecoat	✓	✓
	MacDermid Zinklاد 1000 Black Basecoat + Topcoat (TNT-12)		
<b>Silicate</b>	MacDermid Zinklاد 1000 Clear Basecoat (JS500)	✓	✓
<b>ZnNi E-Plate</b>	MacDermid Zinklاد 1000B Basecoat + Tridip + Cured Topcoat		✓

NYSEAL® 2.0 MAGNI 565		Delamination 5x Install (Pass/Fail)	Pressure Test 10 PSI/1min 5x Install
<b>Organic Coating - Dip Spin</b>	Magni 565 Basecoat only		
	Magni 565 Basecoat + Topcoat (B18)		✓
	Magni 554 Basecoat + Topcoat (B54)		
	Magni 594 Basecoat + Topcoat (T06)		

NYSEAL® 2.0 DOERKEN DELTA		Delamination 5x Install (Pass/Fail)	Pressure Test 10 PSI/1min 5x Install
<b>Organic Coating - Dip Spin</b>	Doerken Delta-Tone 9000 only	✓	✓
	Doerken Delta-Tone 9000+ Delta-Seal Silver		
	Doerken Delta-Protekt KL100 Only	✓	✓
	Doerken Delta-Protekt KL100+Delta-Seal GZ Silver		
	Doerken Delta-Protekt KL120 only		✓
	Doerken Delta Protekt KL120+Delta-Protekt VH301.1GZ		

NYSEAL® 2.0 NOF GEOMET		Delamination 5x Install (Pass/Fail)	Pressure Test 10 PSI/1min 5x Install
<b>Organic Coating - Dip Spin</b>	NOF Geomet 500		✓
	NOF Geomet 321	✓	✓
	NOF Geomet 321 + Topcoat		
	NOF Geomet 720	✓	✓
	NOF Geomet 720+ Topcoat		
	NOF Geomet 430	✓	✓
	NOF Geomet 430 + Plus VLH Black		✓

For more information on Nylok® and NySeal® 2.0, please contact: [sales@nylok.com](mailto:sales@nylok.com). Make sure to also check out our new website at [nylok.com](http://nylok.com)

